



DIP Resistor Settings

Load Shedding	More	R27 < > R1	Less
Temp Sensor	Heater	R28 < > R2	Pool
Pump	1 Speed	R29 < > R6	2 Speed
Circ Pump	Not Fitted	R30 < > R7	Fitted

© **SPA-QUIP** LTD  
 P.O.Box 302-114, N.H.P.C.  
 Auckland, New Zealand.  
 PH 64-9-4158622, Fax 64-9-4158621  
 www.spa-quip.co.nz

<b>P/N SP500A MkII</b>		Issue : Three
<b>Wiring Diagram</b>		
Drawn : SJB 11/06/04	Checked : LH	
Approved :		
Sheet 1 of 1	Not to scale	Size : A4